



DAX EAR PROTECTION MOUNT INSTALLATION INSTRUCTIONS

STEP 1



MARK AND DRILL HOLES ON BOTH SIDES
OF THE HARD HAT

STEP 2



SCREW THE MOUNTS ON AND TIGHTEN

STEP 3



ENSURE SCREWS ARE FIRMLY ATTACHED

STEP 4



REMOVE PREVIOUS BRACKETS, MOUNT
LEFT AND RIGHT DAX BRACKETS

STEP 5



ATTATCH LEFT AND RIGHT EARMUFFS TO
THEIR RESPECTIVE BRACKETS

STEP 6



RE-INSTALL THE LINER
AND THE INSTALLATION IS COMPLETE